
Flood hazard map of Rovaniemi (an observed flood extent 1995-30-05, raw image)



1:50 000

25 m

ERS2 SAR satellite image

Scale (max.):

Ground elevation lines (interval 20 m) Spatial accuracy:

Remote sensed data:

Water level value:

Water level station:

Water level calculation: